



PALLET SCALE
PHA SERIES
User Manual



Thank you for using this hand pallet truck with scale. For your safety and correct operation of the scale, please read these instructions carefully before using it.

NOTE: 1. All of the information reported herein is based on data available at the moment of printing. The factory reserves the right to modify its own products at any moment without notice and incurring any sanction. So it is suggested to always verify possible updates.
(2) Prior to use this hand pallet truck with scale, the battery of scale must be charged enough.

1. GENERAL SPECIFICATIONS

Model	Capacity	Graduation	Weighing Accuracy	Fork size		
				Length	Width over forks	Fork Width
PHA	2000 kg	0.5 kg	± 0.05%	1150mm	540mm	160mm
PHA680	2000 kg	0.5kg	± 0.05%	1220mm	680mm	160mm
PHAS	2000kg	0.5 kg	± 0.05%	1150mm	540mm	160mm
PHAS680	2000kg	0.5kg	± 0.05%	1220mm	680mm	160mm

* Capacity of 3000kg available

* Materials and specifications are subject to change without notice.

2. ATTACH HANDLE TO PUMP UNIT

2.1 Remove the handle component (H100), insert it into the pump shell (B101).


2.2 Remove the axle from plastic bag(B09)

2.3 Insert the axle (B09) at one end of the pump shell(B101), then pump shell (B101) and handle components (H100) connection. Please note axle (B09) the position of the hole, Let the steel wire and nut on the chain (H09) through the axle (B09) hole (See the hydraulic system diagram and the handle component diagram).

2.4 Spring pin (B10) fixed the axle(B09).

2.5 Handle (H01) press the pump plunger(B18), and remove the pin(B11).

2.6 Raise the crank link (B46) and put the pin on rod and chain (H09) into the groove of crank link (B46).



3. TO ADJUST RELEASE DEVICE

On the handle of the pallet truck, you will find the control lever (H01) which can be set in three positions (See Fig. 1): LOWER=to lower the forks; NEUTRAL=to move the load; ASCENT=to raise the forks. After assembling the handle, you can adjust the three positions.

3.1 First tighten the setting screw (B46) on the crank link (B48) until the LOWER position function works.

3.2 If the forks elevate while pumping in the NEUTRAL position, turn the setting screw (B48) clockwise until pumping the handle does not raise the forks and the NEUTRAL position functions correctly.

3.3 If the forks descend while pumping in the NEUTRAL position, turn the setting screw (B48) counter-clockwise until the forks do not lower.

3.4 If the forks do not descend when the control lever (H01) is in the LOWER position, turn the setting screw (B48) clockwise until raising the control lever (H01) lowers the forks. Then check the NEUTRAL position as per item 4.2 and 4.3.

3.5 If the forks do not lift while pumping in the ASCENT position, turn the setting screw (B48) counter-clockwise until the forks elevate while pumping in the ASCENT position. Then check the NEUTRAL and LOWER position as per item 4.2, 4.3 and 4.4.

4. MAINTENANCE

4.1 OIL

Please check the oil level every six months. Total oil amount is about 260 ml, add injection oil 50-100 ml, this must be with the forks in the lowered position.

Add or change the hydraulic oil according to the table below.

Temperature	Oil
-20°C~+40°C	L-HV46 Hydraulic oil

4.2 HOW TO EXPEL AIR FROM THE PUMP UNIT

Air may enter the unit when the seals are replaced. Lift the control lever (H01) to the LOWER position, then move the handle up and down for several times.

4.3 DAILY CHECK AND MAINTENANCE

Daily check of the pallet truck can limit wear and tear of the unit. Pay special attention to the wheels, the axles, the handle, the forks and lift and lower control.

4.4 LUBRICATION

Use motor oil or grease to lubricate all moveable parts.

5. GUIDE TO SAFE OPERATION

For safe operation of the truck, please read all warning signs and instructions here and on the truck before using this truck.

- 5.1 Do not operate the pallet truck unless you are familiar with it and have been trained or authorised to do so.
- 5.2 Do not operate the truck unless you have checked its condition. Give special attention to the wheels, the handle assembly, the forks, lift and the lower control.
- 5.3 Do not use the truck on sloping ground.
- 5.4 Never place any part of your body in the lifting mechanism or under the forks or load. Do not carry passengers.
- 5.5 The operator should wear gloves and safety shoes for protection.
- 5.6 Do not handle unstable or loosely stacked loads.
- 5.7 Do not overload the truck.
- 5.8 Do not subject to unbalanced load, either side to side or along the length of the frame (refer to Fig. 2/B).
- 5.9 The capacity of the truck assumes an evenly distributed load with the centre of the load being at the halfway point of the length of the forks (refer to Fig. 2)
- 5.10 Make sure that length of the forks matches the length of the pallet.
- 5.11 Lower the forks to lowest height when the truck is not being used.
- 5.12 At other specific conditions or places, the operator should operate the pallet truck carefully.

6. TROUBLE SHOOTING

NO	TROUBLE	CAUSE	ACTION
1	The forks do not lift to maximum height.	-Not enough hydraulic oil.	-Add more oil.
2	The forks do not lift up.	-Not enough hydraulic oil. -The oil has impurities. -Discharge valve is out of adjustment. -Air in the hydraulic oil.	-Pour in more filtered oil. -Change the oil. -Adjust the setting screw (B48). -Expel the air.
3	The forks do not descend.	-The rod (B101) and the pump cover (B02) are deformed resulting from a seriously unbalanced load. -A part has been broken or been deformed resulting from unbalanced load. -The setting screw (B48) is not in the correct position.	-Replace the rod (B02) or pump cover (B101). -Repair or replace component. -Adjust the setting screw (B48).
4	Leaks	-Seals worn out or damaged. -Some parts may be cracked or worn out.	-Replace seals with new ones. -Check and replace with new ones.
5	The forks descend without being lowered.	-Impurities in the oil cause the discharge valve (B106) to fail to close. -Air in the oil. -Seals worn or damaged. -Discharge valve (B106) is out of adjustment.	-Replace with filtered oil. -Expel the air. -Replace with new ones. -Adjust the setting screw (B48).


7. WEIGHING OPERATION (Detailed Info Please Refer to Chapter 11 and later).

- 7.1 Put the control lever in the LOWER position and lower the truck to lowest position.
- 7.2 Press the ON key to turn the system on. After the start-up sequence the indicator will display the weight.
- 7.3 Weighing method for gross weight:
Press the ZERO key to set the gross weight to 0. Put the forks under the pallet and check that the load is properly balanced. Put the control lever in the ASCENT position, pump the handle to make the forks rise until the pallet has left the ground. When the indicator is stable, the gross weight of the goods (total weight of the pallet and the goods) is shown.
- 7.4 Weighing method for net weight:
To display the weight of the goods without the weight of the pallet (or another container):
 - 7.4.1 Weigh single standard pallet, for example: weight of pallet: 40kg.
 - 7.4.2 Press the TARE key, the indicator will display "0kg".
 - 7.4.3 Remove the pallet from the forks, the indicator will display "-40kg".
 - 7.4.4 Weigh the goods on the pallet as shown in 7.3, when the indicator is stable, the net weight of the goods is shown.
- 7.5 Switch between kg and lb.
Keep pressing FN key to switch the kg/lb unit (for LED version: keep pressing * key to exchange the kg/lb unit).
- 7.6 Turn off the Indicator
Press on the OFF key to turn off the indicator


8. BATTERY POWER DATA AND REPLACEMENT

- 8.1 How to change batteries:
 - 8.1.1 Loosen the screws of the indicator case and open it.
 - 8.1.2 open the screw on battery and pull out battery, out the socket.
 - 8.1.3 put the new battery and insert the socket.
 - 8.1.4 Screw the bolts and fix it well again

Figure 1



9. WIRING DIAGRAM OF JUNCTION BOX




L0 —Connect meter connector	
GND	silver
—S	white
+S	green
—E	black
+E	red

L1~L4 Connect sensor connector	
GND	silver
—S	white
+S	green
—E	black
+E	red

10. CHANGING THE PAPER (optional with Printer)

10.1 Pull the lever to open the cover of the printer. Place the paper roll. Make sure the flap is at the top of the printer, facing towards you. Hold on to the paper when closing the printer. Push the cover closed firmly.

11. Keypad



Power Off



Power On / ESC



Print / Long press to display time or date



User function set /
Long press to exchange weight unit /
Enter function during parameters configuration



Accumulate /
Long press to retrieve weight records /
Move digits to right during parameters configuration



Tare /
Long press to display percentage function /
Increase the digits during configuration



Zero /
Decrease the digits during parameters configuration

12. Operations

12.1 Switch On/Off

Push [ON] key to turn on the indicator

Push [OFF] key to turn off the indicator

12.2 Zero

If the indicator not on zero point and the weight value <2%F.S., push **[ZERO]** key to zero the scale, and the zero arrow will display

12.3 Tare

Manual Tare: Put the container on the scale (weight>0) and after the read stable (also the tare arrow not appear), push **[TARE]** the scale will remove the weight read and record as tare, and the scale will display the net weight, push **[TARE]** again, it will display the gross weight (tare + net weight)

Repeat Tare: After the first tare operation, put the 2nd weight on the scale, push **[TARE]**, it will display the gross weight of 1st+2nd weight and push **[TARE]** again, it will take that gross weight as new tare weight and start the new net weighing operation.

Remove Tare: When the net weight display and the tare arrow appears, push **[TARE]**, it will remove the tare value and display the gross weight, and the tare arrow disappears.

Auto Tare: When the user function (AUT) set to be 10 or 11 and the weight reach to the valve value as it set, the scale will do tare automatically, refer to AUT configuration.

12.4 Print

On manual print/accumulate mode, when the weight value >20d and stable, push **[PRINT]**, it will print the weight bill, and it can be printed once again if you push **[PRINT]** again.

12.5 Accumulate and Print

On manual print/accumulate mode, when the weight value >20d and stable, push **[ACCU]**, it will print the weight receipt and accumulate to the record (also it will display the accumulation times like [n 12]), next print/accumulating available only after the weight value <20d.

12.6 Weight Unit Exchange

Long press **[FN]** key for 2 seconds to exchange between the 1st unit and 2nd unit.
Kg and lb, g and oz, t only.

13. Accumulated Record Retrieve and Clean

(on weighing mode)

Operation	Display	Explanation
<i>Long Push [ACCU]</i>	[n 12]	Display accumulated times
<i>Push [↑]</i>	[H 3]	Display the first 4 digits
<i>Push [↑]</i>	[L506.5]	Display the following 4 digits, accumulated weight=3506.5
<i>Push [↓]</i>	[n 12]	When it displays the accumulated times, push [↓] to clean the accumulated record
<i>Push [FN]</i>	[0]	Return to weighing mode

14. User Setting Menu

<i>Push [FN]</i>	[Aut 00]	Weighing mode set
<i>Push [FN]</i>	[000200]	Auto tare valve value (when Aut=10 or 11)

<i>Push [FN]</i>	[PrInt]	Communication, Printing Format and Percentage Set
<i>Push [FN]</i>	[PErC]	Set weight value for percentage weighing (100%)
<i>Push [FN]</i>	[SEtP]	Set setpoints
<i>Push [FN]</i>	[PCS]	Set samples quantity (Aut=07)
<i>Push [FN]</i>	[0.002]	10 times resolution
<i>Push [FN]</i>	[0.00]	Return to weighing mode

15. Weighing Mode Set

Operation	Display	Explanation
<i>Push [FN]</i>	[Aut 00]	User functions set
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[Aut 01]	00: Normal weighing mode, manual print/accumulate 01: Normal weighing mode, automatic print/accumulate after the weight stable, auto arrow appears 02: Normal weighing mode, automatic save the weight value, and print/accumulate it after the load < 20d and auto arrow appears 03: Dynamic weighing mode, automatic print/accumulate after the weight <20d, auto arrow appears 04: Peak hold mode, automatic print/accumulate after the weight <20d, auto arrow appears 05: Dynamic weighing mode, manual print/accumulate 06: Peak hold mode, manual print/accumulate 07: Counting mode, manual print/accumulate 08: Positive/Negative weighing, use for testing the tension or compression force 09: Minus weighing mode 10: Automatic tare mode 11: Continuous automatic tare mode Modify the mode and push [FN] to confirm
<i>Push [FN] Push [↑] or [↓] to modify</i>	[Aut 03] [t 3]	If the Aut=03 or 05, there is the time set for dynamic weighing (average weight during the set time) After set done, push [FN] to confirm.
<i>Push [FN]</i>	[0]	Return to weighing mode

16. Communication | Print Configuration

Operation	Display	Explanation
<i>Push [FN]</i>	[Aut 00]	Weighing mode selection
<i>Push [FN]</i>	[PrInt]	Communication, Printing Set
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[Adr 00]	Communication address selection

<i>Push [→] and [↑] or [↓] Push [FN]</i>	[b1 24]	COM1 baud rate select: 24=2400 48=4800 96=9600 144=14400 192=19200
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[CHE1 n]	COM1 Check mode n: None E: Even check O: Odd check S: Always 0 A: Always 1
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[C1 Ct1]	COM1 Output Ct1: Continuous output Cnd: Command (Modbus) F1: Print format 1 F2: Print format 2 F3: Print format 3 Ct2: Stable output Ct3: Continuous output (format = Ct2)
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[b2 24]	COM2 baud rate select: 24=2400 48=4800 96=9600 144=14400 192=19200
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[CHE2 n]	COM2 Check mode n: None E: Even check O: Odd check S: Always 0 A: Always 1
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[C2 Ct1]	COM1 Output Ct1: Continuous output Cnd: Command (Modbus) F1: Print format 1 F2: Print format 2 F3: Print format 3 Ct2: Stable output Ct3: Continuous output (format = Ct2)
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[dF 2]	Date format 0 = d/m/y 1 = m/d/y 2 = y/m/d
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[tlt 2]	Printing head 0: None 1: On top 2: On bottom 3: Both (top and bottom)
<i>Push [↑] or [↓] and [→]</i>	[00~077] [01~079]	Top head input (total 64 letters): 00: The sequence of letter

<i>Push [PRINT] or [ON] to next letter Push [FN] to end</i>	[25~255]	087: ASCII code, 087 represents M, 079 represents O... (refer to appendix I) and input 255 to end the head
<i>Push [↑] or [↓] and [→] Push [PRINT] or [ON] to next letter Push [FN] to end</i>	[00~077] [01~079] [25~255]	Bottom head input (total 64 letters): 00: The sequence of letter 087: ASCII code, 087 represents M, 079 represents O... (refer to appendix I) and input 255 to end the head
	[0.0]	Configuration saved and back to weighing mode

17. Percentage Weighing

Operation	Display	Explanation
<i>Push [FN]</i>	[Aut 00]	Weighing mode selection
<i>Push [FN]</i>	[PrInt]	Communication, Printing Format and Percentage Set
<i>Push [FN]</i>	[PErC]	Set weight value for percentage weighing (100%)
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[3000]	Input the weight value for 100% index
	[0.0]	Back to the weighing mode

Note: Percentage weighing available only when Aut=00, and long press [TARE] for 2 seconds to start the percentage weighing mode.

18. Setpoints

Operation	Display	Explanation
<i>Push [FN]</i>	[Aut 00]	Weighing mode selection
<i>Push [FN]</i>	[PrInt]	Communication, Printing Format and Percentage Set
<i>Push [FN]</i>	[PErC]	Set weight value for percentage weighing (100%)
<i>Push [FN]</i>	[SEtP]	Set setpoints
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[oP 0]	Setpoints mode: oP=0: no output oP=1: 2 setpoints output oP=2: 4 setpoints output (for 3-LED alarming lights) oP=3: 4 setpoints output
<i>Push [→] and [↑] or [↓] Push [FN]</i>	[ALA 0]	Beeper working mode: ALA=0: No beep ALA=1: It beeps when the weight out of range (Hi/Lo, stable) ALA=2: It beeps when the weight within range (OK, stable)
<i>Push [→] Push [↑] or [↓] Push [FN]</i>	[A00500] [000000] [000200]	A setpoint input
<i>Push [→]</i>	[b00700]	B setpoint input

<i>Push [↑] or [↓]</i> <i>Push [FN]</i>	[000000] [000300]	
<i>Push [→]</i> <i>Push [↑] or [↓]</i> <i>Push [FN]</i>	[C01000] [000000] [000400]	C setpoint input
<i>Push [→]</i> <i>Push [↑] or [↓]</i> <i>Push [FN]</i>	[D01200] [000000] [000500]	D setpoint input
	[0.0]	Back to the weighing mode

19. Counting

19.1 Sampling

Put the samples on the scale (if the scale is not zero, please zero or tare the scale firstly) and it's more precise if there are more samples counted (1-999)

Operation	Display	Explanation
<i>Put the samples on the scale</i>	[26.0]	Display the weight of the samples
<i>Push [FN]</i> <i>Push [→]</i> <i>Push [↑] or [↓]</i> <i>Push [FN]</i>	[Aut 00] [Aut 07] [Prnt]	Select Aut=07 (counting mode) Communication and Printing Set
<i>Push [FN]</i>	[PErC]	Set weight value for percentage weighing (100%)
<i>Push [FN]</i>	[SEtP]	Set setpoints
<i>Push [FN]</i>	[PCS]	Set the number of samples, this menu appears when Aut=07
<i>Push [→]</i> <i>Push [↑] or [↓]</i> <i>Push [FN]</i>	[Cnt000] [Cnt030] [C 30]	Input the samples number Example = 30 Save the samples number Ready for counting operation

19.2 Counting

After sampling saved, put the goods on the scale, it will display the quantity of the goods, like [C 108], push [ON] key to shift the display between the quantity or the weight of the goods, and after the weight stable, push [PRINT] or [ACCU] to print the receipt or accumulated receipt.

19.3 Counting Records and Clean

After sampling saved, put the goods on the scale, it will display the quantity of the goods, like [C 108], push [ON] key to shift the display between the quantity or the weight of the goods, and after the weight stable, push [PRINT] or [ACCU] to print the receipt or accumulated receipt.

Operation	Display	Explanation
	[C 108]	On counting mode

<i>Long press [ACCU]</i>	[n 8]	Display the accumulated times
<i>Push [↑]</i>	[C 532]	Display the total quantity
<i>Push [FN]</i>	[C 108]	Back to counting mode
<i>Push [↓]</i>	[n 8]	When it displays the accumulated times, push [↓] to clean the accumulated value and back to counting mode

20. Positive/Negative Weighing

(Aut=08)

On this mode, the indicator can accept the positive or negative signal, when it displays the positive weight, tare operation is available, when it displays the negative weight, the tare operation can't access. Accumulating and printing is unavailable for this mode.

21. Minus Weighing

(Aut=09)

On this mode, the indicator will display the removed load.

Put the object on the scale, long press [ZERO] to zero the scale, now remove the object and the scale will display the removed weight. Tare/Accumulate/Print is available for this mode.

22. Automatic Tare

After Aut=10 or 11 configured, press [FN], it will display the valve value [000200], set the value by [→] [↑] or [↓], if the decimal point set as 0.0, the [000200]=20.0

(Aut=10) Auto Tare

On this mode, when the weight > the valve value, it will do tare automatically.

When the scale back to zero (empty), it will clean the tare automatically.

(Aut=11) Continuous Auto Tare

On this mode, when the weight > the valve value, it will do tare automatically, and now put more objects on the scale, and after the weight stable, press [PRINT] or [ACCU] to print or accumulated print, the scale will do tare again by itself.

When the scale back to zero (empty), it will clean the tare automatically.

23. Clock Adjust

When it display time or date, press [↑] to shift display of time or date.

Operation	Display	Explanation
	[27]	On weighing mode
<i>Long Press [PRINT]</i>	[00:00:80]	Display time (hour/minute/second)
<i>Push [→] and [↑] or [↓] to change</i>	[09:30:01]	After modifying, push [FN] to confirm
<i>Push [↑]</i>	[00.01.01]	Push to [↑] display the date
<i>Push [→] and [↑] or [↓] to change</i>		After modifying, push [FN] to confirm
<i>Push [FN]</i>	[0.0]	Back to the weighing mode

24. Weight Record Retrieve and Print

Operation	Display	Explanation
	[27]	On weighing mode
<i>Long Press [ACCU]</i>	[n 8]	Display the accumulated times
<i>Push [→] Push [↑] or [↓] to change</i>	[000008]	Input the serial number of the weight record
<i>Push [FN]</i>	[r 2]	Display the sequence number of that record
<i>Push [PRINT]</i>	[r 3]	Display the next record
<i>Push [ON]</i>	[r 2]	Display the previous record
<i>Push [↑]</i>	[16.06.03]	Display the date of that record
<i>Push [↑]</i>	[14:53:02]	Display the time of that record
<i>Push [↑]</i>	[30.06]	Display the gross weight of that record
<i>Push [↑]</i>	[20.00]	Display the tare weight of that record
<i>Push [↑]</i>	[10.06]	Display the net weight of that record
<i>Push [↑]</i>	[153]	Display the quantity of that record (for counting)
<i>Push [FN]</i>	[27.00]	Push [FN] to return to weighing mode during any data display (date-time-gross weight-tare weight-net weight-quantity)
<i>Push [PRINT]</i>	[16.06.03]	Push [PRINT] to print the record during any data display
<i>Push [→] and [↑] or [↓]</i>	[b 0001]	Push [→] to input the start number of the records (for retrieve)
<i>Push [FN] Push [→] and [↑] or [↓]</i>	[E 0008]	Input the end number of the records (for retrieve)
<i>Push [FN]</i>	[27.00]	It will print all records from 0001 to 0008 and back to weighing mode after the printing ends.

25. Communication Protocol

Byte format: 8 bits; if there is check bit, it's the first digit; one stop bit

Output format:

1. Continuous format (Ct1, Ct2, Ct3): if the display weight = -123.45

Ct1: no matter the weight stable or not, output continuously:

Adr=00-98: =54.3210=54.3210=54.3210-...

Adr=99: =-0123.45=-0123.45=-0123.45...

Ct2: When the weight stable, output the following ASCII code:

A B CCCCC D E E F G

02, 2D, 30, 31, 32, 33, 2E, 34, 35, 20, 6B, 67, 47, 0D

A	B	C	D	E	F	G
Start 0x02	Sign >=0, 0x20 (space) <0, 0x2D (-)	Weight include decimal point	Space 0x20	Unit kg/lb/t	G/N	Enter 0x0D

Ct3: No matter the weight stable or not, continuous output the Ct2 data.

2. Command (Cnd)

COM1: Modbus

COM2: Handshaking, the computer send the request (ASCII) as below:

P – print gross/tare/net weight

G – Print gross weight

B – Print tare weight

N – print net weight

A – Print quantity

Z – Zero

T- Tare

C – Clean tare

3. Print format (F1)

Weighing Bill	Counting Bill (Aut=07)
MOORANGE ELECTRONICS 03-06-2017 14:58:26 No.0002 G: 7.73kg T: 4.82kg N: 2.91kg www.moorange.com	MOORANGE ELECTRONICS 03-06-2017 14:58:26 No.0002 G: 7.73kg T: 4.82kg C: 54pcs www.moorange.com

4. Print format (F2)

Weighing Bill	Counting Bill (Aut=07)
No.0002 03-06-2017 14:58:26 7.73kg	No.0002 03-06-2017 14:58:26 7.73kg 54pcs

5. Print format (F3)

Weighing Bill
0002 03-06-2017 14:58:26 7.73kg 4.82kg 2.91kg
Counting Bill (Aut=07)
0002 03-06-2017 14:58:26 7.73kg 4.82kg 2.91kg 54pcs

6. Accumulated Format

Weighing Bill	Counting Bill (Aut=07)
03-06-2017	03-06-2017

14:58:26 No.0002 S: 25.02kg	14:58:26 No.0002 C: 108pcs S: 25.02kg
-----------------------------------	--

26. Setpoints Output

A B C D 4 setpoints, $A < B < C < D$

Relay board optional, not included in standard package

26.1 oP=1 (2 relay output 1# and 2#)

$W < A$ or $W > D$: Hi/Ok/Lo LED lights off and no relay output

$A \leq W \leq B$: Lo LED on, 1# relay output

$B < W < C$: OK LED on, no relay output

$C \leq W \leq D$: Hi LED on, 2# relay output

Relay connecting (sharing with RS232C DB9 interface):

Pin6 & pin7: 1# relay NO (normally open)

Pin8 & pin9: 2# relay NO (normally open)

26.2 oP=2 (4 relay output 1#, 2#, 3# and 4#)

If connecting to the 3-LED alarming lights:

1# - yellow, 2# - green, 3# - red, 4# - beeper

$W < A$: Lo LED lights on, 1# and 4# relay output

$A \leq W < B$: Lo LED on, 1# relay output

$B \leq W \leq C$: OK LED on, 2# relay output

$C < W \leq D$: Hi LED on, 3# relay output

$W > D$: Hi LED on, 3# and 4# relay output

Relay connecting (sharing with RS232C DB9 interface):

Pin1: COM

Pin6: 1# relay NO (normally open)

Pin7: 2# relay NO (normally open)

Pin8: 3# relay NO (normally open)

Pin9: 4# relay NO (normally open)

26.3 oP=3 (4 relay output 1#, 2#, 3# and 4#)

$W \leq A$: Lo LED lights on, 1# and 2# relay output

$W \leq B$: Lo LED on, 2# relay output

$B \leq W \leq C$: OK LED on

$W \geq C$: Hi LED on, 3# relay output

$W \geq D$: Hi LED on, 3# and 4# relay output

Relay connecting (sharing with RS232C DB9 interface):

Pin1: COM

Pin6: 1# relay NO (normally open)

Pin7: 2# relay NO (normally open)

Pin8: 3# relay NO (normally open)

Pin9: 4# relay NO (normally open)

27. Trouble Shooting

Problem	Testing Way		Solution
Can't Power On	No Battery Power	Test the battery volume	Charge the battery
	Battery broken	Test the battery volume whether it's lower than 5v	Replace the battery
	No AC power	Whether the cable connected well	Connect it steadily
	No AC power	AC power cable broken	Replace the cable
	Main EEprom broken		Change mainboard or EEprom
RS232 No output	Parameters set wrong	Adr=00 or 99 for continuous output	Choose the right code
	RS232 IC broken	Test the voltage between pin3 and pin5 and it should be between 0.2V-1.2V	Change the IC
Incomplete display		Power on the indicator again to check	Change the LCD
	No backlight	Check the backlight pin loose or not	Re-weld or replace
Display vibrating	Load cell problem	Disconnect the load cell and the display ok	Change the load cell
	Load cell Connect wrong	Disconnect the load cell and the display ok	Check the connecting and correct it
	Battery lower	When the battery volume <10%	Charge the battery
OUER	Overload	The weight >100%F.S. + 9d	Remove the overload weight
	load cell problem	Check the load cell ok and also the connecting correct or not	Recalibrate
-OUER	Minus overload	The weight < -20d or =-100%F.S. on positive/negative weighing mode	Zero/Tare the scale or put the scale pan or cover
	load cell problem	Check the load cell ok and also the connecting correct or not	Recalibrate
Can't Calibrate	IC broken	Test whether there is 2.35-2.6V voltage between +S and -S	Change IC
ERROR	Calibration weight too small	The calibration weight is less than 30%F.S.	Use the right weight
	* Error display may follow by some numbers, it's the same reason		

28. Precaution

- Indicator should be far away from heat resource while using, avoid direct sunlight
- Do not place the indicator in the dusty surroundings or the site vibrant
- Keep out of chemical erosion, operating temperature range will be -10...40°C, relative humidity is no less than 85%, without any corrupt gas in air.
- Never pour the water into the indicator to avoid the damage to the electronic components.
- Housing, head pallet, wire connector should be sealed entirely. Users do not open sealed device or connect with wire without any expert advice. In case any malfunction of indicator occurs, please send the indicator for maintenance.

- The indicator will charge the internal battery at all times when it is connected to the main power.
- When the battery <20%, the battery icon will be empty like  which indicates the recharge on time, when the battery almost empty, the display will twinkle to indicate the immediate charge.
- When the battery used up, the indicator will power off automatically to protect the over-discharge of the battery
- When the indicator set with auto power off, the backlight will off after 30 seconds no operation
- When the indicator set with auto power off, it will turn off automatically after 30 minutes no operation
- When a problem occurs to the indicator, please switch off it immediately and send back to our authorized dealers or our company, for repair
- The warranty period is one year since the delivery date, covering all manufacturing faults. All man-made problems, battery and freight abroad not covered.
- Life-time technical support

