

X1 EN

INDICATOR

VALUE EACH GRAM
HiWEIGH

V.2.2
22/06/2021



INDEX

EN

01

1. INTRODUCTION	
2. KEYBOARD FUNCTIONS	
3. SYMBOLS OF THE SCREEN	
4. TECHNICAL DESCRIPTION	
4.1 Connection of the load cells to indicator	
4.1.1 "7 pin plug"	
4.1.2 "5 pin plug"	
4.2 RS-232 D-B 9	
4.3 Continuous ASCII RS-232 data output format	
4.3.1 Address: Adr=99	
4.3.2 Address: Adr=00	
4.3.3 Address: Adr=1—98 manual and automatic printing output	
5. POWER	
6. CONFIGURATION	
7. CALIBRATION	
8. ZERO	
9. TARE	
10. MANUAL WEIGHT ACCUMULATION	
11. AUTOMATIC MEMORY ACCUMULATION	
12. CLEAR MEMORY	
13. HOW TO SET DATUM	
14. BATTERY CAPACITY	
15. UNIT OF WEIGHING (kg and lb)	
16. CONNECTION TO MINI-PRINTERS	
17. HIGH RESOLUTION DISPLAY MODE	
18. PRECAUTION	

1. INTRODUCTION

A/D resolution	100.000
A/D sampling speed	40 times / second
Excitation voltage	5 V dc; up to 4 load cells 350 Ω , 8 load cells 700 Ω
6-bit display	20 mm LED
Selectable display resolution	1 / 2 / 5 / 0,1 / 0,2 / 0,5 / 0,01 / 0,02 / 0,05 / 0,001 / 0,002 / 0,005 / ...
Serial RS-232 interface	Optional RS-485 interface
Rate continuous ASCII data output	1200 / 2400 / 4800 / 9600 Baud
External power supply	100V - 240V AC
Internal rechargeable battery	6V dc
Operating temperature	de 0°C up to 40°C
Storage temperature	de -25°C up to 55°C
Relative humidity	\leq 85 % non-condensing
Approximate weight	2 kg

2. KEYBOARD DESCRIPTION



OFF function.



ON function.



Function selection during normal operation and configuration.



Manual accumulation function.



Move the flashing digit to the right during configuration or setting preset tare.









Increase the flashing digit during configuration or setting preset tare.




Zero the display, set the zero point or enter a tare value.

3. SYMBOLS OF THE SCREEN


	AC	Main power is applied to the indicator.
		Battery capacity less than 30 %.
	Auto	The automatic accumulation function is active.
		The weight is stable.
	Tare	A weight has been tare, display is showing the net weight.
	Zero	The scale is Zero.
kg		The unit of weighing is kg.
lb		The unit of weighing is lb.

4. TECHNICAL DESCRIPTION

4.1 Connection of the load cells to indicator.



PIN 1	E+
PIN 2	E+
PIN 3	S+
PIN 4	S-
PIN 5	E-
PIN 6	E-
PIN 7	GND shield



PIN 1	+E
PIN 2	+S
PIN 3	-S
PIN 4	-E
PIN 5	GND shield

4.2 RS-232 D-B 9

Pin 3: TXT Output Pin 5: GND

4.3 Continuous ASCII RS-232 data output format

4.3.1 Address: Adr=99

The ASCII data format is "=, X1, X2, X3, X4, X5, X6"

<stx> =, X1, X2, X3, X4, X5, X6

X1, X2, X3, X4, X5, X6 are weight data.

4.3.2 Address: Adr=00

The ASCII data format is "=, X6, X5, X4, X3, X2, X1"


<stx>=, X6, X5, X4, X3, X2, X1

X6, X5, X4, X3, X2, X1 are weight data.



If Address: Adr=99, If the weight is , the continuous output is "=100.00"

If Address: Adr=00, If the weight is , the continuous output is "=00.001"

4.3.3 Address: Adr=1—98 manual and automatic printing output





























































5. POWER

In power off states, press  key turn on the indicator. The indicator will check the LED and display battery capacity  for 1.5 seconds.

6. CONFIGURATION

Connect load cells to the indicator and set following configuration parameters.

Step	Operation	Displaying	Contents
1	Press  and  at same time	Self test from   , to  	In power off states, press  and to turn on, selfcheck, and displaying   edition No 1.5 second.
2	Press 		Enter of the scale. Enter the configuration setting modal.
	Press 		
	Press 		The number of scale divisions selected.
	Press  		1 / 2 / 5 / 0.1 / 0.2 / 0.5 / 0.01 / 0.02 / 0.05 / 0.001 / 0.002 / 0.005 / ... For example: d=0.1
	Press  		
4	Press 		Sets scale F-S
	Press 		Moves the digit at right. For example: F-S=3000
	Press  		
	Press  		
	Press  		
Press  			
5	Press 		Sets display Filter parameters: 00 The display will updata faster and filter faster as the filter parameter is changed from 99-00. For example: FLt=30
	Press 		
	Press  		
	Press  		
	Press  		
6	Press 		Sets automatic power off function. AUtP=00 Not automatic power off. AUtP=01 Automatic power off. Digit express the choice of zero trace range (0-9) 1:0.4d 2:0.8d 3:1.2d 4:1.6d 5:2d 6:2.4d 7:2.8d 8:3.2d 9:3.6d. Decimal digit express the choice of zero set 0. Decimal digit=0 no zero set at start operation. Decimal digit >1 zero set at start operation 20% F-S. For example: AUtP=10 (AUtP=10 when leaving the factory)
	Press 		
	Press 		
	Press  		

*Note: one time accumulation is allowed for weighing once. Following accumulation is allowed for weighing only when displayed value is below 20 d.

7. CALIBRATION

Step	Operation	Displaying	Contents
1	Press FN Press →	CAL SP CAL 00	Enters calibration. Zero the scale.
2	Press FN	----- 3000	Starts zero calibration and wait for calibration to complete.
3	Load the standard weight for F-S on the platform, press FN	----- 3000	Starts calibration and wait for calibration to complete. *If the standard weights can't reach to F.S., 2/3 is recommended to use, press → and ↑ to change the numbers displayed (the weight value of the weight you use) and then press FN to confirm.

Calibration must be done once the parameters are configured.

Pressed **FN** three times during calibration or configuration, the indicator will display. To view the A/D counts, press the **→** key when **-A-d-** is displayed. Press the **FN** key to return to weighing mode.

8. ZERO

When the weight is stable, press **→T←** key for two seconds to set the zero point and zero the display. The **Zero** status LED is turned on.

9. TARE




















Press **→** key, set tare with **→** and **↑** key, then press **→T←** key. The input data is tare. The **Tare** status LED is turned on.




10. MANUAL WEIGHT ACCUMULATION

















When weight is stable, press **M+** key to accumulation the current weight to the total weight. The total number of accumulation will be displayed for **n 12** 1.5 seconds.




11. AUTOMATIC MEMORY ACCUMULATION







Selection of manual/automatic accumulation function (Selection of manual / automatic print function)
 Selection of animal scale, peak value retain and counting function.

Step	Operation	Displaying	Contents
1	Press 		To display times of accumulation.
2	Press 		<p>The selection of manual/automatic accumulation AUt = 0, manual accumulation AUt = 1, automatic accumulation and print when  weight is added, indicator is lit. AUt=2, automatic memorize displayed value when weight is added. Accumulate and print final stable values after load down to below 20 d.  indicator is lit.</p> <p>AUt=3,dynamic weighing method. At weighing >20d: the buzzer sounds "du" and lock is displayed for 6 seconds. Then lock is released for weighing <20d; automatic accumulation and print. Suggest Flt>30.  indicator is list.</p> <p>AUt=4, peak value fixed weighing method. At weighing>20d, the buzzer sounds "du" and lock is displayed. When weighing <20d, fixed data displays with flash, automatic accumulation and print. Lock can be released by pressing any key.  indicator is lit.</p> <p>AUt=5,dynamic weighing method. Manual accumulation and print. AUt=6, peak value fixed weighing method. Manual accumulation and print. AUt=7, counting function. *note</p>
3	Press  x10		Digits displays with flash.
4	Press  x10 Press  x10 Press  x10	   	Move binking digit to the right bit. e.g. AUt=3 expresses dynamic weighing method.
5	Press 		Return to normal weighing status.











* note (1) sampling: when net weight on scale is zero (tare can be removed by pressing tare key if net weight is not zero), the sample, wich must be <200 pieces, i.e. between 1 to 199, is put on the scale. Press  and 
 input quantity of the sample (e.g.30),  is displayed.
 Press ,confirm the completion of sampling. Weighing status is redisplayed. Sampling is memorized even with power off.

Step	Operation	Displaying	Description
1	Place sample		Place selected sample, weight: 27, quantity: 30.
2	Press  Press 	 	Ready to input sample's quantity. Decimal digit display with flash.
3	Press  Press  Press 	  	
4	Press 		Display sample's weight: 27  is a confirmation key, sample collection completed.
5	Press 		Display sample's quantity,  is change-over key

(2) Counting operation: place the object on scale, weight is displayed, press ,  is displayed, and the display changes over to the quantity of the object. When the display is stable, press , accumulate the weight and quantity. Accumulation can be done only at counting status.




Step	Operation	Displaying	Description
1	Place object		Object weight: 230
2	Press 		Object quantity: 255
3	Press 	 	Display after 1.5 seconds at counting status.

Status

Step	Operation	Displaying	Description
1	Press 		Display the total quantity of the object: 1203
1	Press 		Display accumulated weight 4 digits higher.
1	Press 		Display accumulated weight 4 digits lower = 1085
1	Press 		Back to counting status.
1	Press 		Delete accumulated quantity.


(3) Accumulate inquires and delete: both at weighing status.

12 . CLEAR MEMORY

Press  key, if memory has previously been cleared the display will show  followed by zero weight ⁰ when the  key is pressed.


13 . HOW TO SET DATUM

Press  key, move and blinks the current digit to.


Press  key increment the current digit to the next available value.

x10

14 . BATTERY CAPACITY

- When the indicator is being power on/off, battery capacity will be displayed  for 1.5 seconds.
- When the battery capacity is less than 20%, the display will start to blink, power off the indicator to avoid over discharging battery or connect the external main power supply.
- A full charged battery life is approximately 30 hours.

15 . UNIT OF WEIGHING (kg and lb)

kg or lb is selectable. The unit of weighing is kg normally. You can change it to lb by pressing and holding  key 2 seconds at least.


16 . CONNECTION TO MINI-PRINTERS

Connect serial port printer type UP-16TS as follows:



* Note: Before connection to printer, communication address is set as ADR=1; baud rate is set as b=9600.

Print operation with serial port printer is as follows:

16.1 Print: at weighing status, weighing data >20d and display is stable, press  , weighing sheet is printed out. The second printing can be operated only when the weighing data is back to <20d.

16.2 Accumulated print: at weighing status, press  , then press  , accumulated printing can be operated.



16.3 Set to be automatic accumulation status, i.e. automatic print.

At weighing status, weighing data >20d and display is stable, weighing sheet is printed out. The second printing can be operated only when the weighing data is back to <20d and more weight is loaded.

Attached with print sample:

Normal printing	Accumulation printing
No:1 (serial number) Gross: 3940 kg (gross weight) Tare: 2000 kg (tare weight) Net: 1940 kg (net weight)	No:9 (serial numbe) W: 8225 kg (accumulated weight)

17 . HIGH RESOLUTION DISPLAY MODE

In this display mode, press , switch to high resolution display mode.(10timesnormaldisplay)
The last decimal point is light on. Press  key return to normal weight displaymode.

18 . PRECAUTION

- Indicator should be far away from heat resource while using.
- Do not place the indicator in the dusty surroundings or the site vibrant.
- Can not use full capacity. Over load stops hitting platform support is not permitted.
- To ensure to keep out of chemical erosion, Operating temperature range will be -10...50°C, relative humidity is no less than 85%, without any corrupt gas in air.
- Never pour the water into the indicator.
- Housing, head pallet, wire connector should be sealed entirely. Users do not open sealed device or connect with wire without any expert advice. In case any malfunction of indicator occurs, please send the indicator for maintenance.
- The indicator will charge the internal battery at all times when it is connected to the main power.

VALUE EACH GRAM
HiWEIGH